

SANTA CLARA UNIVERSITY	Mechatronics 2024	Andy Wolfe
Lab #8 – Line Follower		

I. Objectives

- Use the line-follower sensor to follow a straight or curved line.
- Determine how the geometry of your robot impacts this task.

II. Pre-Lab

Preparation:

- Study the documents related to the line follower: [QTRX-MD-08RC Reflectance Sensor Array \(digital output\)](#). **Make sure you have the right one!** A user's guide in the datasheet directory on google drive. A software library guide is there as well.
- The best way to install the library is to:
 - In the Arduino IDE, open the "Tools" menu, select "Manage Libraries..."
 - Search for "QTRSensors".
 - Click the QTRSensors entry in the list.
 - Click "Install".
- Determine how you will mount the sensors to your platform for this lab and obtain the necessary materials. The stock screws, nuts, and standoffs will be available in lab (#2 and #4 size) as well as some velcro.
- The QTRX-MD-08RC works best at a specific range of distances from the ground. Determine how far your sensor needs to be from your robot platform and where you will mount it.
- Design some test patterns – 1" wide black lines on white paper. Print them out or bring paper to lab and use black masking tape. You should be able to follow a curve with any radius 200mm or larger, a straight line, and up to a 45° angle.
- Print out or copy a ruler on paper that you can glue/tape to your robot. It should measure 100mm to the left and right of a center point.
- Review the line-follower library and your prior motor code. <https://pololu.github.io/qtr-sensors-arduino/>
Remember to include a calibration process in your system. Also note that there are several routines provided to read the sensors. You can use any or all of them. These may be most useful.

```

void          read (uint16_t *sensorValues, QTRReadMode mode=QTRReadMode::On)
void          readCalibrated (uint16_t *sensorValues, QTRReadMode mode=QTRReadMode::On)
uint16_t      readLineBlack (uint16_t *sensorValues, QTRReadMode mode=QTRReadMode::On)

```

- Think about and discuss an appropriate control algorithm and how to calibrate the control parameters.

Pre-Lab Report:

- Create an accurate measured drawing that represents the position of each of the drive wheels and each of the line-follower photosensors on your robot. You can hand draw or use CAD. A top-projection is acceptable.
- Using these measurements, calculate how the orientation of your robot changes (i.e. the angle), when the right wheel moves forward 1cm and the left wheel simultaneously moves backwards 1cm.
- Using these measurements, calculate how the orientation of your robot changes (i.e. the angle), when the right wheel moves forward 1cm and the left wheel remains still.
- Using these measurements, calculate how the position of each of the 8 photosensors changes (i.e. ΔX and ΔY), when the right wheel moves forward 1cm and the left wheel simultaneously moves backwards 1cm.
- Using these measurements, calculate how the position of each of the 8 photosensors changes (i.e. ΔX and ΔY), when the right wheel moves forward 1cm and the left wheel remains still.
- Wish you had studied harder in Trigonometry.
- Turn in all of your calculations (with explanations) and your drawings.
- Include a selfie of your team's reflection from your planning meeting.

III. Lab Procedure

Line Follower

Task 1:

Line Sensor Operation:

The QTRX-MD-08RC uses an R/C discharge circuit to create a digital timing signal that corresponds to the phototransistor measurement. Luckily, someone has already written the low-level library to interface this device. See https://pololu.github.io/qtr-sensors-arduino/class_q_t_r_sensors.html. This library can be used to read and calibrate the sensors. Make sure you understand the calibration procedure from the documentation.

Mount the QTRX-MD-08RC in accordance with your preparation and connect it to the Arduino. Suitable cables are in the lab. **Don't power anything unless you understand what you are doing, or you will break stuff.** If you need to drill, see the instructor. If your QTRX-MD-08RC does not have connector pins – see the instructor.

Set up part of a 10-wide LED display **with proper current-limiting resistors**. Connect these LEDs to the Arduino such that you can turn 8 adjacent LEDs on and off individually.

Using the QTR library – your program must do the following:

1. Print a prompt on the serial port monitor to calibrate for black. When you press a button or type in something (your choice), perform the black-level calibration.
2. Print a prompt on the serial port monitor to calibrate for white. When you press a button or type in something (your choice), perform the white -level calibration.
3. Enter a loop where you read the 8 sensors using the previous calibration. Compare each reading to a threshold value that determines whether you are seeing black or white. On the 8 LEDs (corresponding to the 8 sensors in order), light the LED's to show white detection and leave the LEDs dark for black detection.

Get black masking tape and white paper from the instructors and make a line. Place the line under the sensor. As you move it left and right, the dark band indication on the LEDs should move as well. (Demo #1)

Include your code and a photo of the system in operation in your lab report.

Task 2:

Do any construction, coding, or circuit design necessary for this task.

1. Mount the line-follower sensor and wheels in the permanent position and orientation that you plan to use for your final project.
2. Develop and test line-following code using the test patterns you developed. You should be able to follow a curve with any radius 200mm or larger and an angle of up to 45°. Initially test with the wheels elevated by moving the black line back and forth and seeing if you get the proper response, then test on the ground/bench.
3. Demo the line follower following at least one non-straight test pattern you developed. (Demo #2)
4. Measure the speed at which your line follower operates (meters/s or feet/s). Include in your report.
5. Measure the maximum deviation from the line. Mark the center of your robot at the front with a pen and mount the paper ruler along the front edge. Use it to estimate the maximum deviation from the line. One good way to do this is to make a cell-phone video from right above, then view it frame by frame on your computer to find the maximum.
6. Lab report should include the measurements from steps 4 and 5 and working code.
7. Demo your line-following with no USB cable on the test courses I will supply. If your line follower works, it should follow my lines as well. (Demo #3)
8. The final project requires that you follow the actual line on the test field. You need to separately demo that for final project credit.